

FEATURES

AeroSpreader S250

Configured for **AeroSpreader S250 (250 kg (33x36x44), AB135 Pull Start 6.5HP, 4" SS Flex Handheld Hose, No Rotate Motor, No Extension Tube, No Gull Wing, Simple Controls, Stationary Skid 250, No Inlet Silencer)**



ENGINEERED DETAILS

Features

Explore the equipment and operating features included in the selected S250 configuration.

 AeroFLOW gentle feed transport AeroFLOW optimizes gentle, air-driven feed transport for reliable, consistent delivery while protecting pellets from damage. Airflow is matched to the feed, route and equipment configuration.	 Pneumatic feed distribution Conveys and broadcasts dry fish-feed pellets using the selected blower, engine and broadcast arrangement.
 Hopper loading Nominal 250 kg marine-aluminum hopper with Slide & Stow lid. Confirm the loading arrangement for the selected hopper.	 Configurable feeding system Combine the blower and engine, broadcast equipment, controls and mobility for the intended feeding arrangement.
 Metering — Manual Manual metering provides operator adjustment of feed delivery from the hopper.	 Hopper Capacity — 250 kg (33x36x44) Nominal 250 kg hopper in the 250 kg (33x36x44) arrangement. Confirm the loading arrangement for the selected hopper.
 Engine — AB135 Pull Start 6.5HP Pair the AB135 blower with a 6.5 hp engine and manual pull starting for a straightforward engine-driven feeding setup.	 Broadcast — 4" SS Flex Handheld Hose Use a 4-inch stainless-steel flexible handheld hose for operator-directed feed placement.
 Control Type — Simple Controls Keep feeding adjustments at the machine with straightforward local controls for blower speed and feed delivery.	 Mobility — Stationary Skid 250 Choose the stationary mounting configuration for a fixed installation on the intended platform, vessel or site.